

POWERING ON AND OFF THE SPORTS SIMULATOR

The Sports Simulator must be turned on in sequence. NEVER hold down the power button. PRESS & RELEASE only.

Please follow these steps in the case of a power outage or system shut down:

To turn the system on:

1. Turn projector on with the white remote.
2. Turn computer on (second shelf), let it start and boot up before turning camera on.
3. Turn camera on (labeled light switch).

To turn the system off:

1. Turn computer off from the menu.
2. Turn off projector with the white remote.
3. Turn off the camera (labeled light switch).